


System Schematic and Parts List for Non-Electronic Trim Tab Controls

Description	Part #	Optional Upper Station	
1 ATC Keypad	AC3250		
2 ATC 6' Keypad Cable	AC32506		
3 ATC Control Unit	AC3400	9 ATC Keypad	AC3250
4 ATC Power Pigtail	AC3121	10 ATC 22' Keypad Cable	AC325022
5 Pigtail for Wire Harness	PT109	11 ATC Hardware Bridge	AC3225
6 ATC 4-Color 6' Wire Harness	WH3006	<i>(not shown)</i>	
7 Relay Module - 12 or 24 Volt	RM12 (or RM24)		
8 ATC Hardware Bag	AC3200		
<i>(not shown)</i>			



System Schematic and Parts List for Bennett Electronic Indicator Control System

Description	Part #	Optional Upper Station	
1 ATC Keypad	AC3250	8 ATC Keypad	AC3250
2 ATC 6' Keypad Cable	AC32506	9 ATC 22' Keypad Cable	AC325022
3 ATC Control Unit	AC3400	10 ATC Hardware Bridge	AC3225
4 ATC Power Pigtail	AC3121		<i>(not shown)</i>
5 Pigtail for Wire Harness	PT109		
6 25' Wire Harness	WH100025		
7 ATC Hardware Bag	AC3200		
	<i>(not shown)</i>		

